

iGo® Multi-Card Reader Software Driver Installation

Mac OS X Installation

NOTE: Driver installation is not required for systems using Mac OS 10.1.2 or above. Simply connect the card reader and access the reader by clicking the "Untitled" HDD icon located on your Desktop.

Windows XP & Windows ME

Driver installation is not required for Windows XP and Windows Me. Simply connect the card reader and access the reader by using the "Removable Disk" icon in "My Computer".

Windows 98 ([Download Drivers](#))

NOTE: Please make sure you install the software driver before connecting your card reader to your computer.

1. Extract the [file you downloaded](#) with a compression tool such as WinZip or WinRaR.
2. Execute "setup.exe"